

1. Remove stock silencer
2. Remove all lower and side body work
3. Remove stock cat box
4. Remove oil cooler bracket
5. Remove all exhaust fixings
6. Remove headers
7. Install Austin Racing headers using stock header nuts and gaskets.
8. Bolt up using M8 x 45mm + penny washer
9. spring on and bolt up slip on
10. Enjoy your Austin Racing AR22 full system!



**Box includes:**

instructions

stickers

Exhaust sticker

spring puller x 1

M8 x 45mm socket head bolt x 1

M8 penny washer x 2

M8 nyloc nut x 1

**GP1/GP2:**

M8 x 25mm socket head bolt x 1

M8 washer x 2

M8 nyloc nut x 1

DB killer x 1 (GP1 - M5 db killer bolt, M5 split washer)

**GP3:**

DB killer x 1 (GP1 - M5 db killer bolt, M5 split washer)

springs with rubbers x 2